



START



Are you using this table to order tugboats in PCS?

NO ▶

Order LAB (Pilot's Number of Tugboats)

YES



Does it concern an LNG vessel or a container vessel longer than 300 metres?

YES ▶

Order LAB (Pilot's Number of Tugboats)

NO



Does it concern special transport?

YES ▶

This table does not apply

NO



Does the vessel have a properly functioning bow thruster and stern thruster and/or multiple properly functioning thrusters?

YES ▶

This table does not apply

NO



Is the destination in the Stad/Botlek region or the Europoort/1st and 2nd Maasvlakte region?

NO ▶

This table does not apply

YES



Choose the correct vessel category. Then determine the vessel's length and draught.



Are you an agent?

YES ▶

Use the minimum number of tugboats from the "min. tugs" column. Do not use the column with wind speed of ≥ 10.8 m/s.

NO



Does the vessel have a properly functioning bow thruster?

YES ▶

Use the minimum number of tugboats from the table

NO



Check the "no bow thruster" column. If it says +1, add 1 extra tugboat.

OUTCOME

Go to PCS and order the number of tugboats. You can enter the minimum number or, if you prefer, a higher number. Do you want the Pilot Service Leader to determine the number? Then enter LAB.